DOMATICA

GLOBAL SOLUTIONS

Quick Start Guide

KNX server

Contents

1 INTRODUCTION 3
2 STEP 1 – POWER UP YOUR KNXSERVER 4
3 STEP 2 – CONNECT YOUR KNXSERVER TO YOUR KNX/EIB BUS 5
4 STEP 3 – SET UP YOUR KNXSERVER 6
4.1 Download and execute the KNXServer Tool 6
4.2 Import your ETS Project File 6
4.3 Deploy Project File to KNXServer 7
5 REGISTER YOU KNXSERVER ONLINE 8

Revision history

Rev #	Date	Authored	Approved	Change description, rationale, location
00	13/04/2015	CR	JF	First Version

1 INTRODUCTION

The purpose of this ***KNXServer Quick Start Guide*** is to introduce the most important features of the product and act also as an executable demo.

All the features are explained in detail in the ***KNXServer User Manual*** (http://support.domaticasolutions.com/support/knowledgebase.php?article=95).

2 STEP 1 – POWER UP YOUR KNXSERVER

Connect your KNXServer to a Power Supply with an output from 12VDC to 30VDC.



WARNING
The KNXServer uses a maximum of 30 Volts DC.
Do not use KNX Bus to power your KNXServer. Use always an external 12 to 30VDC power supply. If your KNX power supply has a second output to power up other devices, you can use-it to power your KNXServer.

3 STEP 2 – CONNECT YOUR KNXSERVER TO YOUR KNX/EIB BUS

Create a network between your KNXServer and your KNX system using a network router and a KNX IP Interface, as shown below.



The router must have access to internet, so that the KNXServer can communicate with the cloud service.

4 STEP 3 – SET UP YOUR KNXSERVER

4.1 Download and execute the KNXServer Tool

Download the KNXServer Tool from the support website.

KNX server Tool

4.2 Import your ETS Project File and Validate the KNX Address functions



4.3 Deploy Project File to KNXServer

Deploy your project to KNXServer by clicking the “Deploy” button



5 REGISTER YOU KNXSERVER ONLINE

First you will receive by email, the entity code, the username and an automatically generated password. Then, when you receive your KNXServer, on the right top of it you have a small label with the serial number and the label key.

Go to http://register.knxserver.com and register your equipment.



Access your KNXServer Cloud Service in http://web.knxserver.com/ using the credentials sent by email and Enjoy!!!

DOMATICA

GLOBAL SOLUTIONS

DOMATICA – Global Solutions, S.A.

Address: Estrada Nacional 247, Edifício nº46, Ribamar

2640-027 Ribamar – Mafra

PORTUGAL

Email: support@domaticasolutions.com

Website: www.domaticasolutions.com

Phone: +351 261 860 030

Fax: +351 261 860 039

KNX server

This leaflet is for general guidance only. Domatica Global Solutions S.A. is pleased to give detailed specifications of its products in this leaflet. As the Company's products and services are continually being developed it is important for customers to check that the information contained herein includes the latest particulars. All items of technical information, advice, know-how, drawings, specifications and other similar items communicated in this document are confidential, and shall not be disclosed to a third party without prior written consent of the publisher. This document is not part of a contract or licence save insofar as may be expressly agreed.